



TUBE CHUTE INSTALLATION INSTRUCTIONS

Step 1: Lay out Chute Tube on floor.
Tubes are marked curbside and roadside at the front header location.

Step 2: Attach Chute Tube to UniMax Header using the Velcro sewn to the tube body.



Step 3: Find the first grommet where the body forms a tube. Pull taut and install 6 inches off the sidewall.



Step 4: Drill and install chute to ceiling between the tube and the UniMax header.

Step 5: Attach the remaining grommets to the ceiling, 3 inches off the sidewall or against the inside edge of the cove mold.



Step 6: Use these steps to attach each tube.

800-233-6180

www.insulatedtransportproducts.com