



DUROMAX

Installation Instructions

#10175 –H Center Support

for trailers 104”+ interior height

- Place two #10175-H Center Supports mounted vertically on the horizontal post below the reefer unit spaced 24” apart.
- Secure Center Supports using two hex head self-taping screws to the horizontal metal support located just below the reefer unit.
- The distance of the center supports and the bottom section of the bulkhead will vary depending on the height of the trailer.

