



Pop-Up Adapter® / Tube Chute® Installation Instructions

**For additional information about the system refer to the Pop-Up® Adapter installation instructions or scan QR codes.*



Step 1: Lay the tube out on the floor. They are marked as “Curbside” and “Roadside”. Position them on the appropriate side of the trailer.



Step 2: Connect each tube to the header using the hook and loop material which is installed on each. *Note: It is important to ensure that the joined components are connected straight and without separations in the hook and loop.*



Step 3: Tensioning the tube against the header, secure the tube to the ceiling using the first grommet. Position this grommet so that it is approximately 1” – 1 ½” from the inside wall. (This is often defined by the width of the corner trim of the trailer).



Step 4: Secure the chute to the ceiling at the approximate midpoint and end of the entire length of the chute, again approximately 1” – 1 ½” from the inside wall.

Step 5: Return to the front of the chute and secure the remainder of the chute to the ceiling by positioning and secure the grommets to as to provide a smooth transition from the header to where the chute becomes a tube. This will vary by application so pre-determined measurements are not practical.

